

Assembly Instructions For The Round Poly Side Table

Tools Needed For Assembly

7/16" Wrench or Socket
Screwgun
Square Drive Bit

Parts List

Table Top (1)
Leg Assemblies (2)
Braces (2)

Hardware

1/4"x 2-3/4" Carriage Bolts (4)
1/4" Flange Nuts (4)
1-1/2" Polybuster Screws (8)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Align the holes in the top of the leg assemblies with the holes in the 1x2 support strips underneath the table top. Place the leg assemblies on the outside of the 1x2 strips, insert the 2-3/4" carriage bolts, put the flange nuts on the inside and tighten.
- Step 3** Fasten the braces to the leg assemblies on the sides that don't have any braces. Fit the braces in between the braces that are already attached on the leg assemblies. (The legs might need to be pushed in or out slightly so they align perfectly). Fasten with the 1-1/2" screws in the predrilled holes and turn into the legs. Screws are self drilling.

