


Features and Materials


Solids: Oak Veneers: Oak, Birch, Ash Panels: Moisture Resistant MDF Installation Type: Freestanding Number of Basins: Two, With Optional 3cm Top Vanity Top Included: No, Optional 3cm Tops Available with Sinks Overflow: Yes, Front Facing Number of Doors: Two Number of Drawers: Five Removable Organizer with Aluminum Laminate Liner Drawer Box Material and Finish: Oak, Birch, Ash Veneers over Moisture **Resistant MDF English Dovetail Joinery** Aluminum Laminate Drawer Liners USB/Power Component: Yes, (ETL5011080) Cord Length: 6'6 Assembly Type: Installation of Optional 3cm Top with Sink Assembly Type: Cabinet comes fully assembled Hardware Material and Finish: Stainless Steel in Champagne Brass Fits Drain Hole Size: 1 3/4" Full Extension, Soft Close Glides European Soft Close Hinges Adjustable Levelers

Dimension


Width: 71-3/4" Depth: 23-3/8" Height: 34-3/4" Rough-In Height: 21-1/2"













All dimensions and specifications are nominal and may vary. Use actual products for accuracy in critical situations Diagrams are of cabinets only - Optional Countertops and sinks are not shown.







Side View 2

Side View 1


All dimensions and specifications are nominal and may vary. Use actual products for accuracy in critical situations Diagrams are of cabinets only - Optional Countertops and sinks are not shown.



Silestone® by Cosentino

Silestone is a hybrid surface of premium minerals, recycled materials, resins, and pigments that produce a hygienic, high-performance, stain and scratch-resistant surface.

The production process of Silestone employs an innovative and sustainable technology known as HybriQ. This groundbreaking technology employs an innovative hybrid composition that significantly reduces the utilization of crystalline silica, ensuring that it does not exceed 50%. This revolutionary formulation is meticulously crafted utilizing 99% recycled water and 100% electrical energy derived exclusively from renewable sources.





Silestone Care and Maintenance

Silestone's hybrid composition consisting of premium minerals, quartz, and recycled materials makes it highly resistant to stains, preventing them from penetrating the surface and making daily cleaning easy and quick.

Routine Care: Simply wipe your Silestone surface with soap and water on a regular basis to maintain its beauty. For deeper cleaning, use any Ph-balanced (less than 10) general-purpose household cleaner. Q-Action cleaner is especially effective for the disinfection of kitchen countertops.

Using sealants and water repellants is not necessary to maintain the original sheen of your Silestone quartz top. Avoid using these products as they can create an undesirable build-up over time. If the surface of your Silestone countertop loses sheen, you may apply food-safe furniture spray.

Light Stains: Apply a small amount of a general-purpose household cleaner to the stain, let sit for 2 minutes and rub with a non-scratch scouring pad. Rinse immediately with water. For stains that harden as they dry, remove by gently scraping the surface with a razor blade or putty knife, holding it upright to avoid scratching the surface. Clean using warm, soapy water and rinse thoroughly.

Difficult/Stubborn Stains: The following products may be applied and let stand for 10 minutes before scrubbing and rinsing thoroughly. Caution should be exercised in the handling and storage of these chemicals.

Lacquer Thinner - Rubbing Alcohol - Ammonia - Mineral Spirits

Hardwater Stains: Apply a paste from equal parts baking soda and white vinegar. Let sit on the surface for 10-20 minutes and rub with a non-scratch pad. Rinse immediately with water.

General Precautions

Avoid using the following:

- Chlorine-based products
- · Degreasing agents such as those used in oven cleaners
- Products high in alkaline (Ph over 10)

Heat Precautions

Although Silestone can withstand high temperatures for short periods of time, its performance varies with respect to different factors like thickness, color, location, etc. For this reason, it is not recommended that the product be exposed to sustained contact with a heat source, like curling irons, nor should hot saucepans, frying pans, deep-fat fryers, etc, be placed on it. The use of a hot pad or trivet is recommended in such situations.

Sun Exposure

- · Silestone quartz is not intended for outdoor use
- Avoid places with UV lighting


Repairs

One of the most effective solutions for repairing scratches is to carefully fill them with grout or silica gel. Marble paste is also highly effective.

Because each type of damage needs to be carefully considered to determine the proper care method, we recommend consulting a professional.

SNK-RF RECTANGULAR PORCELAIN UNDERMOUNT SINK





EXTERNAL DIMENSIONS:

Length: 19-1/2" Width: 14-3/8" Height: 6-7/8"

INTERNAL BASIN DIMENSIONS:

Basin Length: 17-1/8" Basin Width: 12" Basin Depth: 4-3/8" Fits Drain Hole Size: 1-1/2"

All dimensions are nominal


Visit website for more information www.onfloatingvanity.com




IMPORTANT STEPS BEFORE YOU BEGIN

- Ensure the vanity cabinet is in place and has been properly installed to meet plumbing codes. For your safety and to achieve the best possible results, James Martin Vanities recommends you consult with a professional contractor.
- Shut off the water supply. Water supply and drain access must be in place prior to installing the countertop and sink.
- Ensure the vanity cabinet is level.

TOOLS AND MATERIALS: (Not included)




SINK MOUNTING HARDWARE (Included)




PROPER HANDLING OF 3CM COUNTER TOP

Carefully unpack the countertop and place finished side down on flat, soft and sturdy surface.

Important: The countertop is very fragile. Take caution when handling, and have someone assist you.



Rotate carton from flat position and lift top vertically.





Lift top vertically with two people.



NEVER LIFT OR CARRY THE VANITY TOP FLAT.





Visit website for more information www.onfloatingvanity.com

2




Assembly Instructions (Countertop & Sink)


SINK INSTALLATION

IMPORTANT: Make sure all surfaces are clean. Place top finished side down on a soft surface.


1. Using a tape measure, draw a straight 3" line marking the center points of all sides of the sink cut out.




 Carefully unpack the undermount sink and place on a soft surface, bowl side up. Using a tape measure, identify and mark center point on all sides of the bottom and profile of the lip of the sink.




3. Carefully lift the sink and place it centered over the countertop cutout, bowl side up and with the overflow drain at the opposite end from the faucet holes. Align all marked center points along each side of the lip of the sink, with the marked center points along cut out in the countertop. Ensure the sink is centered over the opening and carefully trace around the perimeter of the sink with a marker.




 Carefully lift the sink from the countertop and place it on a soft surface, bowl side down. Apply a bead of silicone sealant around the top edge of the sink rim.



 Carefully lift and turn the sink over on the countertop, positioning it within your marked outline, ensuring again that the overflow is opposite from the faucet holes. Once positioned, press firmly in place.



7. Attach sink clips by placing the contoured end of the bracket against the sink lip, aligning the open, notched area over the threaded inserts. The bracket will be at a slight angle, and the angle will vary depending on the thickness of the sink lip. Insert the set screw. Allow sealant to dry as indicated by manufacturer. Although the sealant is what secures the sink to the top, we suggest keeping the clips in place after installation.



Visit website for more information www.onfloatingvanity.com

ON

Assembly Instructions (Countertop & Sink)


IMPORTANT

- Ensure the vanity cabinet is in place and has been properly installed to meet plumbing codes. For your safety and to achieve the best possible results, James Martin Vanities recommends you consult with a professional contractor.
- Shut off the water supply. Water supply and drain access must be in place prior to installing the countertop and sink.
- Ensure the vanity cabinet is level.

PREPARING THE VANITY CABINET FOR INSTALLATION OF THE COUNTERTOP AND SINK

IMPORTANT: Make sure all surfaces are clean.


8. Apply an adhesive around the top edge of the vanity cabinet. Add an extra dot on all 4 corners of the vanity top.




- **9.** With assistance from another person, carefully lift the countertop with sink to a vertical position and ease onto the vanity cabinet, front edge first.
- **Important:** The countertop is very fragile. Take caution when handling, and have someone assist you.



10. Once positioned, press firmly into place. Wipe away any excess sealant using a damp cloth.



11. If you are installing a wood back-splash (available on specific models), place a generous amount of silicone sealant on the back of it and press it into place against your bathroom wall. Fill any gaps that are left with silicone sealant. Wipe away any excess sealant with a damp cloth.



- **12.** Once assembled allow the silicone sealant to fully dry according to the manufacturer's recommendation. When dry, proceed to the installation of your faucet and drain.
- **13.** For stone tops, such as marble and granite, it is recommended that you apply a high quality sealer to protect from staining and discoloration. Stone sealer should be reapplied once or twice per year, depending upon usage, according to sealer's instructions.

4