Breton Modern Vanity Installation Instruction

PARTS LIST											
NO.	PARTS	NAME	QTY	NO.	PARTS	NAME	QTY				
1		Hangs board	1	4		Cabinet body	1				
2		Plastic expansion tube	4	5	********	M6x65 Screw	2				
3	1	M4x60 Countersunk head screw	2	6		Basin	1				
		(5)			Install ha	Installation S	teps (1				
	Hang up	the cabinet	2		Fix the ca	binet by ②⑤					
		stall the basin	4			ished	(1)				

Breton Modern Vanity Installation Instruction

PARTS LIST											
NO.	PARTS	NAME	QTY	NO.	PARTS	NAME	QTY				
1		Front aluminum frame	2	6	1	M4x14 Flat head tapping screws	16				
2	€*	M4x10 Countersunk head screw	12	7	\Diamond	Board	1				
3		25x25x430 Aluminum bar with spacing strip	1	8	\Diamond	Board	1				
4		25x25x430 Aluminum bar with holes	2	9	\Diamond	Board	1				
5		25x25x430 Aluminum bar	2	10		Cabinet body	1				
	_((-	9 9	V	Installation Step	os (1)				
	Frame	nstallation	2		Board :	Installation	3				
		Connection	4		Fini	shed	5				