



1. Fold creases A B C D at 90 degree's.
2. Fold creases E F G H at 90 degree's.
3. With the male section on the outside insert male D shaped lock 1 into female C shaped slit 3, Then similarly 2 into 4. Repeat at each corner.

