

CONVERSION TOP CADDY ASSEMBLY INSTRUCTIONS

(Reference illustration on page 2)

Step #1: Attach stretcher assembly (#4) to both bottom support assemblies (#3) using machine screws (#8).

Step #2: Attach each side panel (#2) to each bottom support assembly (#3) using machines screws (#8).

Step #3: Slightly spread the side panels and hold the storage box assembly (#1) in place. Secure, through the lower hole in each side panel (#2), with machine screw (#7).

Step #4: Attach hold down assemblies (#5) to the storage box (#1) through the upper hole in each side panel (#2) using flat washer (#6) and machine screw (#7).



