



Suggestion Notes.

1. Tack the complete project up before performing any welds.
2. Place tack welds on all corners joining any member meeting that corner.
3. To further challenge your abilities plate A should remain in the flat position during welding.
4. Pay attention to weld sequence in order to cover up starts/stops and provide a visually appealing project.

TITLE:

Aluminum Practice Project

DWG. NO.

WS-AL.25-18