



Suggestion Notes.

- 1. Tack the complete project up before performing any welds.
- 2. Place tack welds on all corners joining any member meeting that corner.
- 3. To further challange your abilities plate A should remain in the flat position during welding.
- 4. Pay attention to weld sequence in order to cover up starts/stops and provide a visually appealing project.

TITLE:

Steel Practice Project

DWG. NO.

WS-ST1-4-19

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WELDERMADE.COM. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WELDERMADE.COM IS PROHIBITED.

weldermade.com

SHEET 1 OF 1