



BMW 1 Series 2008



BM-51-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, marking pen, Phillips screw driver

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8X1/2" screws

LOCATION: Right of Radio

Step 1: Begin by removing the wood grain trim piece above the radio and below air vents (picture 1). Place the tip of the DTRT underneath the wood grain trim piece starting on the driver's side of the trim piece at the upper left hand side of the radio. Use the DTRT in a gentle twisting motion, releasing a series of five (5) retainer clips moving from left to right. Once the trim piece has been removed, simply set it carefully off to the side.



Step 2: Place the VSM G3 in the mounting location just as pictured (picture 2). Be sure the outside of the bend on the VSM G3 runs parallel to the highlighted ridge on the dash (picture 2). Once the VSM G3 is correctly in position as pictured, use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Use a 5/64" bit and drill to drill out the marked locations. DO NOT DRILL MORE THAN 1/4" DEEP! Place the VSM G3 over the appropriate pilot holes and tighten the VSM G3 to the dash with the three (3) provided #8X1/2" screws and a Phillips screw driver.



Step 3: Once the VSM G3 is flush to the dash molding and in position, place the trim piece back into place over the VSM G3. You have successfully installed your VSM G3!




Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™.

Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



© Pro.Fit International, Eagan, MN 2009

View Instruction & Updates
Online at
www.pro-fit-intl.com