



Jeep Grand Cherokee 2011-2013



BM-53-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screwdriver, 5/64" bit and drill, marking pen

PARTS INCLUDED: VSM G3 bracket, Lock Plate, J Stem, one (1) #8 x 1/2" screws

LOCATION: Upper Left corner of radio

STEP 1. Carefully insert the Dash Trim Removal Tool (DTRT) between the radio bezel and the rest of the dash molding (radio bezel includes the climate control, air vents, too just above the cubby hole). Use the DTRT in a gentle twisting motion to release a series of eight (8) retainer clips securing the radio bezel to the dash molding. Move the DTRT around the bezel carefully, and once you have released all eight retainer clips, simply allow the bezel to hang gently out of the way. There is no need to disconnect the bezel wiring



STEP 2. Remove a series of four (4) 7mm bolt screws securing the radio to the sub dash molding and place them carefully aside. Gently pull the radio out just enough to be able place the VSM G3 in its mounting location as pictured in pic 1. Be sure to note that the factory bolt is placed through the right-most hole and that the mount rests between the sub dash molding and the radio (pic 1). Use a 5/64" bit and drill to drill out the left-most hole. Do not drill more than 1/4" deep! Use a Phillips screw driver and the supplied #8 x 1/2" screw to secure the left-most hole to the sub dash structure.



STEP 3. Once the VSM G3 is secured and flush to the dash molding, simply snap the dash bezel back in place (pic 2). You have successfully installed your VSM G3!



Note: Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM-G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 or 800.388.0073 Fx: 952.641.4701

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Bloomington, MN 2011

View Instruction & Updates
Online at
www.pro-fit-intl.com