



Chevrolet HHR 2008-2009

CV-56-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, marking pen, Phillips screwdriver

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of Radio

STEP 1. Insert the DTRT in the space between the climate control and the radio/climate control dash as shown in Photo #1. Use the DTRT with a gentle twisting motion around the bezel to release a series of nine (9) retainer clips that secure the bezel to the dash molding. After the retainer clips have been released, simply disconnect the wiring to the bezel and place the bezel carefully aside.



STEP 2. Identify the location of the dash molding in which the VSM G3 is to be mounted. Photo #2. With the VSM G3 flush and in place, use a marking pen to mark the locations of the pilot holes. Remove the mount and use a 5/64" bit and drill to drill out the marked locations of the pilot holes. Do not drill more than 1/4" deep. Place the VSM G3 flush over the pilot holes and tighten the VSM G3 evenly to the dash molding with the three (3) provided #8 x 1/2" screws.



STEP 3. When the VSM G3 is secured and flush to the dash molding, assemble the dash in the reverse order in which it was dismantled. You have successfully installed your VSM G3.



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com