



Chevrolet Suburban and Tahoe (2007-2012)
 Chevrolet Avalanche (2007-2009)
 Chevrolet Silverado LTZ 1500,2500, 3500 (2007-2012)
 GMC Sierra SLT 1500, 2500, 3500 (2007-2012)
 GMC Yukon (2007-2012)

PART NUMBER: CV-71-07

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 5/64" drill bit and drill, # 2 Phillips screwdriver, # 2 Phillips screwdriver, dash trim tool (DM-40-22)

PARTS INCLUDED: Pro.Fit VSM®, three (3) # 10 x 1/2" screws, instructions.

LOCATION: Right of Radio

STEP 1.

Insert dash trim tool behind upper right corner of radio trim bezel. **Photo 1.** Pry gently to release retainer clip. Work tool clockwise around bezel releasing four (4) clips on right side and four (4) on left and one at bottom center. Lift bezel off and set aside.



STEP 2.

Align the Pro.Fit VSM between the center retainer clips on the right side of the radio. **Photo 2.** Using the VSM as a guide, mark the location of three (3) screw holes. Set Legend aside. Drill three (3) pilot holes at the marked location using a 5/64" drill bit and drill. Align the Legend over the pilot holes, insert three (3) # 10 x 1/2" screws and tighten.



STEP 3. Re-assemble the dash in reverse order. This completes the installation of your Legend.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM-G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 or 800.388.0073 Fx: 952.641.4701

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Bloomington, MN

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**