



INSTALLATION INSTRUCTIONS

CADILLAC ESCALADE (1999-2000)
GMC YUKON, YUKON DENALI, TAHOE, SIERRA (1995-2000)
GMC & CHEVROLET TAHOE, SUBURBAN, C/K PICKUP(1995-2000)
 (ALL TRUCK MODELS ARE OLD BODY STYLE AND A/T ONLY)

PART NUMBER: **CV-71-95**

VIEW INSTRUCTIONS & UPDATES
 ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, 9/32" socket, ratchet, 5/64" drill bit and drill.

PARTS INCLUDED: Pro.Fit VSM™, one (1) #10x3/4" screw, one (1) #8x3/4" screw, instructions.

LOCATION: Below climate control

STEP 1.

Begin by removing four (4) 9/32" bolts along the bottom of the panel under the steering column. Release the six (6) retainer clips on panel. There are three (3) clips on right and three (3) on left of the steering column. Work your hand under the panel and gently pull loose. Panel does not need to be completely removed. Let the panel hang.

STEP 2.

Note - Step 2 must be followed exactly. Loosen the two (2) 9/32" bolts that hold the cup holder in place. Place Pro.Fit VSM™ into position placing slots on right side of mount behind the factory screws. **IMPORTANT!!! DO NOT TIGHTEN BOLTS AT THIS TIME!!!** Apply upward pressure to mount, holding it up against dash. Locate hole in Pro.Fit VSM™ that is to the left of the "U" shaped cutout. Using 5/64" drill bit and drill, drill starter hole. Insert and secure one (1) #8x3/4" screw. Using 5/64" drill bit and drill, drill starter hole, in hole that is above and to the left of the "U" shaped cutout in Pro.Fit VSM™. Insert #10x3/4" screw and secure. Tighten factory bolts resecuring cup holder.

STEP 3.

Re-install trim panel. Reinstall four (4) factory screws. Install hang up cup onto Pro.Fit VSM™.

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003