



**CADILLAC** Escalade (2001-2006)  
**CHEVROLET** Avalanche (2002-2005), Pickup (2000-2006)  
 Suburban (2000-2006), Tahoe (2000-2006)  
 Classic Silverado (2007)  
**GMC** Denali, Yukon, Yukon XL (2000-2006),  
 Pickup (2000-2006)  
 Sierra 2500HD SLE & SLT (2007) *All New body style*



## PART NUMBER: CV-71-99-L

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.**

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**TOOLS REQUIRED:** 9/32" socket & driver.

**PARTS INCLUDED:** Pro.Fit Legend, instructions, two (2) #8 1/2" screws.

**LOCATION:** Right of the air vent

**STEP 1.** Begin by removing the trim bezel that surrounds the instrument cluster, radio, and climate control. This bezel extends from the left of the steering wheel to the right of the radio. Slide ashtray out. With your hand palm side up, grasp the lower section of the bezel just above the ashtray. Pull toward you to release the first clip. Using the same action, continue working the bezel loose in a counter clockwise motion releasing a total of eleven (11) clips. **NOTE:** For automatic transmissions with a column shift only. Apply the emergency brake. Insert the key and turn the ignition to the "on" position. Place the transmission into low gear.



**STEP 2.** If applicable, tilt the adjusting steering wheel to its lowest position. Grasp the trim bezel and carefully pull it away from the dash. Set the bezel aside. Place the transmission back into park and turn the ignition to the off position.



**STEP 3.** Locate two (2) 9/32" hex-head screws right of radio. Remove the screws with the 9/32" socket and driver. Align the Legend over the two screw holes. Insert the bottom factory screw first and tighten. Then insert the top screw and tighten.



**STEP 4.** Re-assemble the dash in reverse order. Install the phone holder onto the Legend.

This completes the installation of your Pro.Fit Legend.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

