



Dodge Charger 2008-2010
Dodge Magnum 2008-2010
Chrysler 300 C 2008-2010



PART NUMBER: DG-51-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" drill bit and drill, #2 Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8x1/2" screws

LOCATION: Right of Radio

STEP 1. Place the DTRT in the upper right hand corner near the air vent of the bezel surrounding the radio. Using a gentle twisting motion, begin to carefully release the seven clips securing the bezel to the dash molding in a clockwise rotation around the bezel. The climate control will release with the bezel. Be sure to disconnect the wiring to the bezel and carefully place aside.



STEP 2. Use a Phillips screw driver to remove the four (4) screws securing the radio to the dash molding. Carefully pull the radio out of the dash molding; do not disconnect the wiring to the radio. Wrap the radio in a protective cloth and simply allow it to hang out of the way.



STEP 3. Place the VSM G3 in position and flush to the dash molding as pictured in Photo #2. Using the VSM G3 as a guide, use a marking pen to mark the location of the pilot holes. With a 5/64" drill bit and drill, carefully drill out pilot holes over the marked areas; be sure not to drill too deep. Place the VSM G3 over the pilot holes and secure the VSM G3 to the dash molding with the two (2) provided #8 x 1/2" screws.



STEP 4. Re-assemble the dash in reverse order. Remember to reconnect all wiring. This completes the installation of your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com