

2019 Chevrolet Silverado 1500
2019 GMC Sierra 1500
PART NUMBER: DG-53-07-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Electric Screw Driver OR Cordless Drill, Phillips Screw tip, T15 Screwdriver

PARTS INCLUDED: VSM G3, A Plate, J-stem, 2-#8 x 1/2" screws

LOCATION: Right of Radio

Step 1: Using the DTRT remove silver bezel around the radio (held with retainer clips) and set aside. Then remove the four T15 torque screws attached to the radio and climate control.

Step 2: Pop loose the radio, starting at the top of the radio using your hands (also held with retainer clips). Do not remove all the way. Only loose enough for room to attach mount.

Step 3: On the right side of the right vent, just below where the opening starts to angle up to the left.

Place the mount and mark the holes for the mount. Either pre-drill pilot holes or attach using your cordless drill.

Step 4: Reverse steps 2 and 1.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

[View Instructions &
Updates Online at
www.pro-fit-intl.com](http://www.pro-fit-intl.com)