



INSTALLATION INSTRUCTIONS

DODGE RAM PICKUP (1998)
(A/T only) (See reverse side for 1999-2002 instructions)

PART NUMBER: DG-70-98

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit MOUNT.
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 2 Phillips screwdriver, 10mm socket & driver, 5/64" drill bit & drill.

PARTS INCLUDED: Pro.Fit custom mount, instructions, two (2) #10x5/8" screws.

LOCATION: Below the radio.

STEP 1. Open up the power outlet door and locate and remove one (1) Phillips head screw using your # 2 Phillips screwdriver . Set screw aside. Open up both the cup holder door and the ashtray door. **Remove the dash trim bezel that surrounds the radio and climate control and extends across the instrument cluster.** To do this, grasp the bezel with your hands on the bottom right side of bezel just above the cup holder door pulling toward you to release a series of clips. Once released, work the remaining clips loose by pulling toward you all the way around the bezel. There are a total of fourteen (14) clips. When the bezel is loose disconnect the wiring harness to the power outlet and set bezel aside.

STEP 2. Using a 10mm socket & driver locate one (1) screw below and to the left of the radio holding the radio in place. Remove that screw and set it aside. Pull that corner of the radio out just far enough to slide the **Pro.Fit** mount behind the radio mounting bracket. Align the slot in the **Pro.Fit** mount with the screw hole and slide the radio back into place. Insert the factory screw and tighten with 10mm socket & driver.

STEP 3. Using the remaining holes in the **Pro.Fit** mount as a guide, drill two pilot holes using a 5/64" drill bit and drill. Insert the two (2) screws provided and tighten with # 2 Phillips screwdriver.

STEP 4.
 Re-assemble dash in reverse order and install hang up cup onto **Pro.Fit** mount.

This completes the installation of your **Pro.Fit** mount.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit** custom mount. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.
Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
Web Address: www.pro-fit-intl.com



INSTALLATION INSTRUCTIONS

DODGE RAM PICKUP 1500 (1999-2001)
DODGE RAM PICKUP 2500, 3500 (1999-2002)
(A/T only) (See reverse side for 1998 instructions)

PART NUMBER: DG-70-98

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™. All instructions assume a drivers seat vantage point. * Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 2 Phillips screwdriver, 10mm socket & driver, 5/64" drill bit & drill.

PARTS INCLUDED: Pro.Fit VSM™, instructions, two (2) #10x5/8" screws.

LOCATION: Below the radio.

STEP 1. Open up both the cup holder door and the ashtray door. **Remove the dash trim bezel that surrounds the radio and climate control and extends across the instrument cluster.** To do this, grasp the bezel with your hands on the bottom right side of bezel just above the cup holder door pulling toward you to release a series of clips. Once released, work the remaining clips loose by pulling toward you all the way around the bezel. There are a total of fourteen (14) clips. Set bezel aside.

STEP 2. Using a 10mm socket & driver locate one (1) screw below and to the left of the radio holding the radio in place. Remove that screw and set it aside. Pull that corner of the radio out just far enough to slide the **Pro.Fit VSM™** behind the radio mounting bracket. Align the slot in the **Pro.Fit VSM™** with the screw hole and slide the radio back into place. Insert the factory screw and tighten with 10mm socket & driver.

STEP 3. Using the remaining holes in the **Pro.Fit VSM™** as a guide, drill two pilot holes using a 5/64" drill bit and drill. Insert the two (2) screws provided and tighten with # 2 Phillips screwdriver.

STEP 4.

Re-assemble dash in reverse order and install hang up cup onto the **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **Pro.Fit International**, Eagan, MN 2003