



INSTALLATION INSTRUCTIONS

CHRYSLER PACIFICA (2003-2006)

PART NUMBER: **DG-71-04**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 2 Phillips Screwdriver, Dash Trim Removal Tool (DM-40-22)

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: Right of Climate Control

STEP 1.

Insert the dash trim removal tool behind the trim bezel, left of the climate control. **(Photo # 1)**. Pry outward to release a retainer clip. Pull outward on the bezel with your hands to continue loosening the bezel. Swing the bezel off to the side to reveal two (2) Phillips screws. **(Photo # 1)**. Remove the screws.



STEP 2.

Align the **Pro.Fit VSM** over the two (2) screw holes. Reinsert the screws and tighten. **(Photo # 2)**. Replace the trim bezel.




This completes the installation of your **Pro.Fit VSM**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fax: 651-688-9876

Web Address: www.pro-fit-intl.com



© **Pro.Fit International**, Eagan, MN 2005