## Chevrolet Colorado 2014-2018 GMC Canyon 2014-2018

PART NUMBER: DG-71-05-L

## \*PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3\*

All instructions assume a drives seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properlyy installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Electric Screw Driver OR Cordless Drill, Phillips Screwdriver

PARTS INCLUDED: VSM Legend, 2-#8 x 3/8" Screws

LOCATION: Right of Radio

Step 1: Use your DTRT to pop loose the bezel around the radio and climate contrail. (Photo #1)

Step 2: Remove the four screws in Photo #1 while holding the radio and climate control. Remove this assembly and there is no need to disconnet any of the wries. Set the assembly aside to continue working.

Step 3: Align the VSM Legend mount on the right lower side of the radio and climate control area, just below the bottom outside retainer clip slot (Photo #2). Mark with a sharpie the location of the mount holes to drill pilot holes or use your cordless drill to attach using the provided screws.

Step 4: Reassemble, return radio and climate control unit to it's original location. Return the four screws holding it into place. Pop the bezel back on to complete the install.







Pro.Fit International, Inc. \* may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1<sup>st</sup> Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty

View Instructions & Updates Online at www.pro-fit-intl.com

Advanced