



Jeep Liberty 2008-2010

DG-92-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screwdriver

PARTS INCLUDED: VSM G3, A Plate, J Stem

LOCATION: Right of Radio

STEP 1. Apply the emergency brake and place the vehicle into neutral. Use the DTRT in a gentle twisting motion around the shifter bezel in order to release four (4) retainer clips. Do not remove the shifter bezel, simply pull it back away from the radio/ climate control bezel.

STEP 2. Insert the DTRT in the upper right hand corner of the radio/climate control bezel near the air vent. Again use a gentle twisting motion around the radio bezel to release a series of six (6) retainer clips. Place your hand under the bottom of the radio bezel and gently pull it out enough to gain access to the Phillips screws securing the right side of the radio to the dash molding.

STEP 3. Remove the two Phillips screws on the right side of the radio. Place the VSM G3 over the two screw holes just as shown in Photo #3. Replace the two screws and evenly tighten the VSM G3 to the right side of the radio. Make sure that the VSM G3 is flush and tight to the contours of the radio.

STEP 4. Replace the bezel carefully back in place. You have successfully installed your VSM G3.

Note: Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 551420, Ph: 952.641.4700 Fx: 952.641.4701

Installation Difficulty
 ● ● ○ ○ ○
 Simple Advanced

© Pro.Fit International, Bloomington, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com