



Dodge Challenger 2009-2011

DG-92-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screwdriver

PARTS INCLUDED: VSM G3, Lock Plate, J Stem

LOCATION: Right of Radio

Step 1: Place the DTRT in between the radio bezel and the dash molding **Photo #1**. Gently use the DTRT in a twisting motion around the radio bezel releasing a series of eight (8) retainer clips. Do not disconnect any wiring to the bezel and simply set the radio bezel off to the side.



Step 2: Remove the upper right hand corner Phillips screw securing the right side of the radio to the dash molding and carefully set it off to the side. Place the VSM G3 flush to dash molding over the screw hole and evenly tighten the VSM G3 to the right side of the radio molding as pictured in **Photo #2**. Be sure highlighted edge is snug to dash.



Step 3: Once the VSM G3 is flush and secured to the right side of the radio, replace the radio bezel back into its secured original position. You have successfully installed your VSM G3!



Note: Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2009

View Instruction & Updates
 Online at
www.pro-fit-intl.com