

Chevy Express Van 2012-2019

PART NUMBER: DG-92-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 9/32 socket and Ratchet

PARTS INCLUDED: VSM G3, J-Stem, Lock Plate, Washer

LOCATION: Right of Radio

Step 1: Set the emergency brake and place gearshift into drive. Next, remove the lower dash panels on the driver and passenger side. Each panel has two (2) screws on the bottom and six (6) clips on the driver's sidekick panel and four (4) retainer clips on the passenger sidekick panel. Remove the bottom screws and pull out gently on the panel to release the retainer clips. Set both panels aside.

STEP 2. Using your hands, pull outward on the dash bezel, starting below the radio. Work your way around the dash, pulling outward, until all clips are released. **TO AVOID DAMAGE, DO NOT TRY TO REMOVE THE DASH.** Disconnect the wiring to the power outlet in the lower right corner of the dash.

Step 3: Remove the top Bolt on the right side of the radio. Place bolt through the mount then place the washer on the backside. Reinsert the bolt, mount and washer to the bolts original location. Before tightening all the way down, make sure mount is above tab on the side of the radio. Then tighten the remainder.

Step 4: Reverse steps 2 and 1. Make sure you position the mount through the radio open of the bezel and hook and wires back up to the power outlet before pushing retainer clips back in place.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

[View Instructions & Updates Online at www.pro-fit-intl.com](http://www.pro-fit-intl.com)