



Ford Focus 2008-2009

FO-50-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, marking pen, Phillips screwdriver

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws



LOCATION: Right of Air Vent

STEP 1. The dash bezel above the glove box must first be removed. In order to do this you must first insert the DTRT in the space between the bezel and the dash molding in the area pointed out in Photo #1. Use the DTRT in a gentle twisting motion; work the tool around the bezel until all six (6) retainer clips have been released. The bezel is also held in place by a 7mm bolt as pictured in Photo #2. You do not need to release this bolt, simply pull back on the bezel in order to free up enough space for you to continue the installation.

STEP 2. Place the VSM G3 flush to the dash molding and in position as pictured in Photo #3. Once the VSM G3 is in place, use a marking pen to mark the locations of the pilot holes. With a 5/64" bit and drill, drill out the marked locations. Be careful not to drill more than 1/4" deep. Place the VSM G3 over the appropriate pilot holes and evenly tighten the VSM G3 with a Phillips screwdriver to the dash molding with the three (3) #8 x 1/2" screws.

STEP 3. Once the VSM G3 is secure and in position, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com