

Ford Freestyle (2005-2007) Ford Taurus X 2008

PART NUMBER: FO-61-05-L



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DM-40-22), #2 Phillips screwdriver, 5/64" drill bit


and drill

PARTS INCLUDED: Pro.Fit Legend, instructions, two (2) #8 x 1/2" screws.

LOCATION: Right of radio

STEP 1.

Open the compartment door above the two air vents. Insert a dash trim tool behind the lower right corner of the trim bezel, near the 12 Volt power outlet. Pry outward to release a retainer clip. Work the trim tool and your hands around the bezel, pulling outward until the entire bezel is released. Do not disconnect the bezel from the dash. **Photo 1.**



STEP 3. Using the Legend as a guide, mark the location of two (2) screw holes. Set Legend aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the Legend over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.


STEP 4. Re-assemble the dash in reverse order. This completes the installation of your Legend.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit Legend**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit** International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM