

GMC Acadia 2013-2016

PART NUMBER: FO-61-05-L

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Box Knife, 9/32 Socket, Socket Wrench

PARTS INCLUDED: VSM Legend

LOCATION: Right of Radio

Step 1: Using a DTRT, remove the bezel trim around the radio and set aside, which is held on with retainer clips. (Photo #1)

Step 2: Using a sharp box knife or razor blade, cut the 1/8" thick excess black plastic on right hand side of radio at the bottom bolt for the radio. Around 2" top to bottom. See picture #2 for reference. The plastic being cut is excess from injected molding.

Step 3: Remove right bottom bolt from radio. Loosen the other 3 bolts. Pull the radio out enough to slide mount behind the radio from either the top or bottom. Line up the radio bolt hole with mount hole and bolt into place. Make sure the piece with the Hazard lights button is into position correctly and tighten other 3 bolts.

Step 4: Pop back on the bezel trim.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

View Instructions &
Updates Online at
www.pro-fit-intl.com