



Ford Expedition 2007-2010

PART NUMBER: FO-72-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 7mm socket and driver

PARTS INCLUDED: VSM G3, A Plate, J Stem

LOCATION: Right of Radio

STEP 1. Begin by inserting the DTRT into the dash bezel to the right of the radio. Release the first of six (6) clips located in the top right hand corner of the dash bezel that surrounds the radio and climate control. Work the DTRT in clockwise rotation around the bezel. After the dash bezel has been released, remove the wiring connected to the bezel and place the bezel aside.



STEP 2. Locate the two (2) 7mm bolts securing the right side of the radio as shown in Photo #2. Remove these bolts and secure the VSM G3 flush to the radio as pictured; be sure to tighten the bolts evenly and completely over the VSM G3 tabs.



STEP 3. Once the VSM G3 is secure and flush, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3.



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com