



FORD F250, F350, F450, F550
Super Duty Pickup (A/T only)
(2005-2007)

PART NUMBER: FO-73-05-L



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DM-40-22), #2 Phillips screwdriver, 5/64" drill bit and drill

PARTS INCLUDED: Pro.Fit Legend, instructions, two (2) #10 x 1/2" screws

LOCATION: Below climate control

STEP 1.

Set the parking brake, put gear shift into low and adjust steering wheel in the down position. Insert dash trim tool behind upper-left corner of dash bezel and pry outward, releasing a retainer clip. Work the tool clockwise around the bezel, pulling outward until all clips are released. Disconnect wiring to headlight switch, pedal control and 12 volt power point. Move dash out of the way. **Photo 1.**



STEP 2.

Place Legend mount against dash, following contours. Align the right edge of the Legend with plastic edge behind the fan switch. **Photo 2.**



STEP 3.

Using the Legend as a guide, mark the location of two (2) screw holes. Set Legend aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the Legend over the pilot holes, insert two (2) # 10 x 1/2" screws and tighten.



STEP 4.

Re-assemble the dash in reverse order. This completes the installation of your Legend.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

