

Chrysler Pacifica 2017-2018

PART NUMBER: HO-51-09-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Electric Screw Driver

PARTS INCLUDED: VSM G3, J-Stem, Lock Plate, 2-#8 x 3/8

LOCATION: Above right vent

Step 1: Using the DTRT and your hand pop the black bezel with the radio screen and vents loose. They are held in with retainer clips. This now can be set aside. (Photo #1)

Step 2: Pop loose the silver trim starting from the passenger side to just right of the driver's seat by pushing the retainer clips from the backside and pulling light from front. The trim is one piece through to the gauges (Photo #2).

Step 3: Align the G3 mount in the upper right-hand corner, just to the left of the retainer clip slot (Photo #3) Mark the top screw hole spot. Drill a pilot hole where the mark you just made or use your drill to screw in the screws provided.

Step 4: Reverse steps 1 and 2 to complete installation.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

[View Instructions & Updates Online at www.pro-fit-intl.com](#)