



Honda Accord 2008-2009



HO-57-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, marking pen, Phillips screwdriver

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8X1/2" screws

LOCATION: Right of Radio

Step 1: Insert the DTRT in the space between the dash molding and the trim piece that runs to the right of the radio and above the glove compartment (**Photo #1**). Gently use the DTRT in a twisting motion in order to release a series of eight (8) retainer clips. Place the trim piece safely aside.



Step 2: Place the VSM G3 flush and in position exactly as pictured (**Photo #2**). Once the VSM G3 is in position, use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Use a 5/64" bit and drill to drill out the locations of the pilot holes. **DO NOT DRILL MORE THAN 1/4" DEEP!** Place the VSM G3 over the pilot holes and secure the VSM G3 to the dash molding with the two (2) provided #8X1/2" screws and a Phillips screw driver.



Step 3: With the VSM G3 flush and secured to the dash molding, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3.



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty

● ○ ○ ○ ○

Simple Advanced