

Ford Taurus 2013-2015

PART NUMBER: HO-71-06-L

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Cordless Drill

PARTS INCLUDED: VSM Legend, 2-#8 x 3/8

LOCATION: Top of radio

Step 1: Using the DTRT, remove the dash panel just above the radio that are held by retainer clips. (Photo #1)

Step 2: Place mount on the right side of the center plastic tab and mark hole location or using a cordless drill screw in provided screws. (Photo #2)

Step 3: Place removed dash panel back in location and tap it back into place.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

View Instructions &
Updates Online at
www.pro-fit-intl.com