



Honda Pilot 2009-2010



HO-74-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Marking Pen, 5/64" bit and drill, Phillips screw driver

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8X1/2" screws

LOCATION: Right of Radio

Step 1: Remove the plastic trim bezel surrounding the right side air vent. Place the DTRT in the space between the radio and the air vent trim bezel. **Photo #1.** Use the DTRT in a gentle twisting motion around the air vent bezel releasing a series of retainer clips. **NOTE:** Open the glove box in order to make it easier for you to fit the tool in between the air vent bezel and the dash molding. Work the tool all the way around the air vent bezel, do not disconnect any wiring and simply allow the bezel to hang out of the way.



Step 2: Place the VSM G3 flush to the dash molding, aligning the rectangular hole directly over the retainer clip hole just as pictured in **Photo #2.** Make sure that the retainer clip will fit through the rectangle cut in the VSM or the dash will not fit back together properly. Once the VSM G3 is flush and in place, use it as a stencil to mark the locations of the pilot holes. With a 5/64" bit and drill, drill out the two (2) marked pilot holes. **DO NOT DRILL TO DEEP, ONLY 1/4".** Tighten the VSM G3 to the dash molding with the two provided #8X1/2" screws and a Phillips screw driver.



Step 3: Once the VSM G3 is flush, secured, and in position, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ● ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2009

[View Instruction & Updates Online at www.pro-fit-intl.com](#)