



Hyundai Sonata 2006-2008

HY-55-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips screw driver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, one (1) #8X1/2" screw

LOCATION: Below and to the right of radio

STEP 1. Open the glove box and remove the two Phillips screws that secure the wood grain trim piece that runs across the dash, see Photo #2. Place the DTRT beneath the wood grain trim piece and the dash molding above the glove box. Use the DTRT in a gentle twisting motion to release a series of retainer clips along this trim piece starting at the glove box and moving towards the steering wheel. Once all the retainer clips have been released, simply place this trim piece carefully off to the side.

STEP 2. Locate and remove the Phillips screw pictured in Photo #3. Place the VSM G3 flush to the dash molding and over the screw hole. Replace the screw and tighten the VSM G3 to the dash. Next use a 5/64" bit and drill and carefully drill out the pilot hole just to the left of the Phillips screw. Do not drill more than 1/4" deep! Place the provided #8X1/2" screw in the pilot hole and tighten it to the dash with a Phillips screw driver.

STEP 3. Once the VSM G3 is secure and flush to the dash molding, replace the dash together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com