



## Dodge Sprinter 2008-2009



Part Number: IF-71-03-G3

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.**

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).**

**Tools Needed:** Dash Trim Revmoval Tool, Star pattern screw driver, 5/16" drill, drill bit, phillips screw driver.

**Parts Included:** Pro.Fit VSM G3, two # 8 x 1/2" screws

**Location:** Right of Climate Control

### Step One:

Begin by inserting the Dash Trim Removal Tool in the upper right hand corner of the dash face bezel directly above the radio. This plastic bezel is held on by a total of seven (7) clips. After carefully popping open the first clip in the upper right hand corner of the radio bezel, carefully work open the bezel by removing each clip one at a time in a clockwise rotation. There is a clip placed in the center of the bezel right below the radio to take note of. After removing the bezel carefully disconnect the wiring to the bezel and set the bezel aside.



### Step Two:

Once the bezel is set aside, the climate control pad must be removed. The climate control is held in place by four (4) star patterned screws. Remove these screws and pull the climate control out of the dash. **Do not** disconnect the climate control, and simply allow the climate control to carefully hang down in front of the dash.



### Step Three:


Place the VSM G3 in the location as instructed by photo #2. Once the VSM G3 is in place, mark the pilot holes in the VSM using a marker. Using a 5/16" drill bit, very carefully drill the pilot holes over the area you have marked. Place the VSM G3 over the drilled holes and secure the VSM to the dash using the two (2) provided screws.



### Step Four:

Once the VSM G3 is secured and in the correct position, put the dash back together in the reverse order that it was dismantled. You have successfully installed your Pro.Fit VSM G3.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM G3™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates  
Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)