

Chevrolet Colorado 2004-2010 GMC Canyon 2004-2011 Isuzu i-Series Pickups 2004-2007



PART NUMBER: IF-71-03-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM G3.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: #2 Phillips screwdriver, Dash Trim Removal Tool (DM-40-22), 5/64" drill bit and drill

PARTS INCLUDED: Pro.Fit VSM G3, two # 8 x 1/2" screws

LOCATION: Right of radio

STEP 1.

Insert the dash trim removal tool behind the trim bezel, above the right air vent. (Photo # 1). Pry outward to release a retainer clip. Work the removal tool counterclockwise around the bezel until all clips are released. Disconnect the wire harness on the back side of the bezel. Set bezel aside.

STEP 2.

Place the Pro.Fit VSM G3 against the dash pad above the right corner of the radio, aligning the bottom of the G3 with the small ledge . (Photo # 2). Using the G3 as a guide, mark the location of two (2) screw holes. Set G3 aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the G3 over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.

STEP 3.

Re-assemble the dash in reverse order, remembering to reconnect the wiring harness. This completes the installation of your Pro.Fit VSM G3.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM G3[™]. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

