

Ford Escape 2008-2012 Mercury Mariner 2008-2012 Mazda Tribute 2008-2010



Part Number: IF-71-03-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

Tools Needed: Dash Trim Revmoval Tool (DM-40-22), 5/64" Drill Bit and Drill

Parts Included: Pro.Fit Legend, two #8 x 1/2" screws

Location: Right of Radio/Air vent

Step One:

Place the Dash Trim Removal Tool in the upper right hand corner of the dash trim bezel, just to the right of the radio display and air vent. There are four (4) clips holding this bezel in place. Pop each clip carefully and work the tool in a counter-clockwise rotation around the dash bezel. After releasing the clips, place the bezel carefully aside.



Step Two:

Place the VSM G3 flush against the ridge of the dash as shown in picture (1). Once you have the VSM G3 in place, use the VSM G3 as a guide and mark the location of the two mounting holes. Using a 5/64" drill bit, carefully drill out the pilot holes in the marked location. Place the VSM G3 over the marked location and tighten using the provided screws. Reassemble the dash in reverse order. This completes the installation of your **Pro. Fit VSM G3**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this
Pro.Fit VSM©. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.
Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 Fx: 952.641.4701