



Toyota Highlander 2008-2011

IF-71-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips Screw driver, 5/64" bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right or Left side of Air Vent

STEP 1. Insert the DTRT in the space between the radio and the air vents just above the "Eject" button on the radio. Twist gently to release retainer clips securing the air vents to the dash molding, until a total of 5 clips have been released. Remove the air vent assembly and carefully set it off to the side.



STEP 2. Place the VSM G3 flat and flush to the dash molding as pictured in Photo 2. You can place the VSM G3 either to the right or left side of the air vent cavity in the exact location as pictured, depending on your preference.



STEP 3. After the VSM G3 is flush and in location, use a marking pen to mark the locations of the pilot holes. With a 5/64" bit and drill, carefully drill out the pilot holes making sure not to drill more than 1/4" deep. Place the VSM G3 over the pilot holes and secure it to the dash molding using the provided #8 x 1/2" screws and a Phillips screw driver.



STEP 4. Once the VSM G3 is secure and flush to the dash molding, place the air vent assembly back into place, making sure that all the retainer clips are secured. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com