



Volvo XC90 2005-2009

IF-71-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips Screw driver, 5/64" bit and drill, T-25 Torx driver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of Radio

Step 1: Open the cup holder door on the center console. With your fingers, carefully lift up evenly on the back of the shifter bezel to release four (4) retainer clips (shift bezel and shift indicator assembly will release together). Release the shift indicator assembly from the shifter bezel by pressing on four (4) clips located underneath the shifter bezel and pull the shift indicator assembly down. Apply the parking brake and shift the vehicle into drive in order to allow enough room to expose the two (2) Torx screws securing the radio/climate control.

Step 2: Use a T-25 Torx driver to release the two screws pictured (Photo #2). Place a protective towel on the center console. Gently pull on the bottom of radio/climate control assembly in the area in which you have just released the two (2) Torx screws. Pull the entire radio/climate control out, guiding the wires out carefully, and place it on the center console out enough to provide the space needed for the VSM G3 installation.

Step 3: Place the VSM G3 flush and in position on the dash molding. You can place the VSM G3 anywhere along the groove pictured (Photo #3). Once the VSM G3 is in your desired position, use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Use a 5/64" bit and drill to carefully drill out the marked locations of the pilot holes. **DO NOT DRILL MORE THAN 1/4" DEEP!** Place the VSM G3 over the pilot holes and secure it to the dash molding using the two (2) provided #8X1/2 screws and a Phillips screw driver.

Step 4: Once the VSM G3 is flush and secured to the dash molding, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.



Install anywhere
along ridge

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com