



INSTALLATION INSTRUCTIONS
KENWORTH T600, T800 (1985-99)
(Standard Dash only.)
PART NUMBER: KW-30-85-CARD

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: T-30 Torx Driver.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: To the left of the glove box behind dash panel.

STEP 1.

Remove the dash panel that is to the left of the glove box. To do this, locate two Torx screws in the top left and top right corners of the panel. Remove the screws using the Torx driver. Set screws aside.



STEP 2.

Grasp the panel with both hands and pull it out of its cavity letting it hang. Locate the top right screw hole that holds the panel in place. Place the **Pro.Fit VSM™** over this screw hole aligning the hole in the **Pro.Fit VSM™** with the screw hole. Replace the dash panel and insert and tighten factory screws.



STEP 3.

Install the phone holder onto the **Pro.Fit VSM™**.
 This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com