



Kenworth

T-660, T-800, W-900, C500

2008-2012

KW-31-08

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screw driver

PARTS INCLUDED: VSM

LOCATION: Right of radio

STEP 1. Insert the DTRT in the space between the dash molding and instrument cluster bezel to the right of the radio. Photo #1. Use the DTRT in a gentle twisting motion in order to release a series of retainer clips securing the instrument bezel to the dash. Carefully pull back the bezel to reveal a Phillips screw just below the radio.



STEP 2. With the instrument bezel pulled out just enough to access the Phillips screw, remove the screw and place the VSM in place as pictured in Photo #2.



STEP 3. Replace the screw and tighten the VSM flush to the dash. As soon as the VSM is flush and in position, simply secure the instrument bezel back in place. You have successfully installed your Pro.Fit International VSM.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55121, Ph: 952.641.4700 Fx: 952-641-4701

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Bloomington, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com