



## KENWORTH T2000 (1997-2004)

PART NUMBER: **KW-32-97**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** #2 Phillips screwdriver, T-20 Torx driver (1997-2001 only)

**PARTS INCLUDED:** **Pro.Fit VSM™**, instructions.

**LOCATION:** Upper Right Corner of Dash

**Please note the slight difference in the installation procedure for 1997-01 T2000 models and 2002-04 models.**

**1997-2001 Models** have (2) Torx screws holding the switch panel.  
**2002-2004 Models** use Phillips screw instead of Torx.

### STEP 1.

Locate the switch panel that is just above the radio. Using the Torx driver, remove the two (2) Torx or Phillips screws that hold it in place and carefully pull the panel away from the dash. **Do not disconnect any wiring.** Install the phone holder onto the Pro.Fit custom mount.



### STEP 2.

Place the **Pro.Fit VSM™** over the right screw hole behind the panel. Place the panel back over the **Pro.Fit VSM™**, aligning the screw holes. Insert the two (2) factory Torx screws and tighten.



This completes the installation of your **Pro.Fit VSM™**.



**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM®**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

