

Ford F150 (1997-2003) (A/T ONLY), F150 Heritage (2004) (A/T ONLY) Ford F250 - "Light Duty Pickup" (1997-2000) (A/T ONLY)

Ford Expedition (1997-2002) (A/T ONLY)

Lincoln Navigator (1998-2002)

Lincoln Blackwood (w/o GPS) (2001-2002)

PART NUMBER: LC-70-98

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro. Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 9/32" Socket and driver. PARTS INCLUDED: **Pro.Fit VSM®**, instructions. LOCATION: Below the automatic climate control.

STEP 1.

Begin by removing trim bezel that surrounds the radio and auto climate control. Using your hands grab bezel at upper right corner slowly working around with fingers to release six (6) clips (two (2) on the top of bezel, two (2) on the bottom and two (2) on the sides.) **Do not disconnect wiring**. Let bezel hang to left side.

STEP 2.

With 9/32" socket and driver locate and remove four (4) 9/32" screws that hold auto climate control in place. Set screws aside. Slide auto climate control out of its cavity and let hang to the right side. It is not necessary to remove the radio. **Do not disconnect wiring**.

STEP 3.

Place the **Pro.Fit VSM**© in the auto climate control cavity aligning the **Pro.Fit VSM**© with the screw hole in the lower left corner of the cavity. Slide the auto climate control unit back into the cavity, making sure that it clears the two bezel clip holes on the right and left sides. **HINT:** Apply downward pressure on the auto climate control unit in order for the centering pins and four screw holes to line up. Install the four (4) factory screws that hold the auto climate control in place and tighten down with 9/32" socket & driver. Reinstall trim bezel securing the six (6) clips.

STEP 4.

Reassemble dash in reverse order.

This completes the installation of your **Pro.Fit VSM**®.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM**©. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit** International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

