

Ford Crown Victoria (1995-2010) Mercury Grand Marquis (1995-2010) Mercury Marauder (2003-2005)

PART NUMBER: MR-51-95

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 9/32" socket and ratchet, #2 Phillips screw driver, 5/64" drill bit and drill

PARTS INCLUDED: **Pro.Fit VSM**®, instructions, two (2) #10x5/8" screws

LOCATION: To the right of the Climate Control

STEP 1.

Begin by removing the trim panel that surrounds the climate control and runs horizontally across the entire length of the dash. Grasp the right edge of the panel near the passenger door and pull outward, releasing a retainer clip. Work your hands to the left, continuing to pull outward on the panel until all clips are released. There are seven (7) clips on top and two (2) clips below the climate control.

STEP 2.

Using a 9/32" socket, remove the bolt located to the right and above the climate control that secures the dash trim panel. Slide tab of **Pro.Fit VSM®** under trim tab of dash panel, aligning holes. Replace the factory bolt. Do not tighten at this point.

STEP 3.

Putting downward pressure on the VSM®, drill two (2) pilot holes with a 5/64" drill bit and drill. Insert two (2) #10 x 5/8" screws and tighten. Tighten factory bolt. Reinstall trim bezel.

This completes the installation of your **Pro.Fit VSM®**.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

