



# Mazda 3 2006-2008

## MV-25-03-G3



### PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).**

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), 5/64" drill bit and drill, marking pen, Phillips screwdriver

**PARTS INCLUDED:** VSM G3, A Plate, J Stem, three (3) 8 x 1/2" screws

**LOCATION:** Right of radio

**STEP 1.** Insert the DTRT behind the trim piece to the right of the radio display. This trim piece surrounds the radio display and continues along through passenger molding. It is held in place with four (4) clips, with an "L" clip tab holding the trim piece in place near the passenger side door. After the four (4) clips have been released, slide the trim piece towards the steering wheel in order to release the "L" clip. Carefully set the trim piece aside.



**STEP 2.** Removing this trim piece will reveal four (4) screws that need to be removed. The bottom two screws secure the radio into the dash molding and the top two screws secure the air vents to the dash molding. Remove these four (4) screws and begin to gently pull the radio straight out of the dash. The display is connected to the radio, and by removing the screws securing the air vents, you should have provided ample clearance to be able to remove the entire radio and display. Once you have removed the radio from its cavity, disconnect the wiring to the radio and carefully set it aside.



**STEP 3.** Place the VSM G3 exactly in place as pictured in Photo #2. Using the G3 as a guide, mark the location of the pilot holes with a marking pen. Drill out the marked locations using a 5/64" drill bit and drill. Be sure not to drill too deep. Place the VSM G3 over the pilot holes and secure it to the dash molding using a Phillips screwdriver and the three (3) provided #8 x 1/2" screws.



**STEP 4.** Once the VSM G3 is flush and secured in place, begin to assemble the dash back together in reverse order. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this

VSM-G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 or 800.388.0073 Fx: 952.641.4701

**Installation Difficulty**  
      
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates  
 Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)