



# Chevrolet Monte Carlo 2006-2007 Chevrolet Impala 2006-2010



MV-25-03-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), Phillips screw driver, 5/64" drill bit and drill, marking pen

**PARTS INCLUDED:** VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

**LOCATION:** Right of Radio

**STEP 1.** Insert the DTRT behind the lower-right hand corner of the trim bezel that surrounds the radio and climate control. With a twisting motion, gently pry out and release a total of six (6) clips securing the bezel to the dash. Set bezel aside.



**STEP 2.** Remove the Phillips screws from each side of the climate control. Slide climate control out of its cavity, wrap in a protective cloth and let it hang down. Remove the two (2) screws from each side of the radio. Slide radio out of its cavity, wrap in a protective cloth and let it hang down. Do not disconnect either the radio or climate control. Photo #1.



**STEP 3.** Place the VSM G3 against the dash pad, to the right of the radio as pictured in Photo #2. Using the holes in the VSM G3 as a guide, mark the pilot holes with a marking pen. Set the mound aside. Carefully drill pilot holes with a 5/64" bit and drill. Align the VSM G3 over the pilot holes, insert provided screws, and secure the VSM G3 to the dash pad.



**STEP 4.** Assemble the dash in reverse order, securing all clips. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty  
      
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates  
 Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)