



Dodge Nitro 2008-2009

MV-25-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screw driver, 5/64" drill bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of Radio

STEP 1. Remove the rubber liner from the tray located above the two air vents, revealing two Phillips screws. Remove the screws and insert the DTRT between the tray and the dash molding. Use a gentle twisting motion to pry the tray from the dash and set aside.



STEP 2. Once the tray has been removed, place the DTRT in the upper right hand corner of the radio/climate control bezel. Again use a twisting motion to release all of the retainer clips around the bezel. Remove the wiring and carefully place the bezel aside.

STEP 3. Remove the four (4) Phillips screws securing the radio to the dash. Pull the radio straight out and wrap in a protective cloth. Simply allow the radio to hang out of the way. Do not disconnect radio wiring.



STEP 4. Place the VSM G3 flush against the dash as pictured in Photo #2. Using the VSM G3 as a guide, mark the location of the pilot holes with a marking pen. Use a 5/64" bit to drill out the marked pilot holes. Only drill to a 1/4" depth; be careful not to drill too deep! Place the VSM G3 over the pilot holes and secure the mount to the dash with a Phillips screw driver and the three (3) provided #8 x 1/2" screws.



STEP 5. Once the VSm G3 is secured and in place, place the dash back together in the reverse order from which it was dismantled. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty

 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com