



Ford Econoline 2001-2008

E150, E250, E350, E450

MV-25-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Ford DIN Radio Removal Tools (DM-10-22) Phillips screw driver, 5/64" drill bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right or left side of Radio

STEP 1. Insert the DIN tools into each side of the radio face about 3/4" at a slight outward angle until you feel them catch. Do NOT insert the tools too far as this can damage the release clips. Apply gentle pressure outward (apart) on both tools while pulling radio out of dash (Note: complete instructions for use of this tool included when purchased from Pro.Fit). Disconnect the radio wiring harness and antenna lead. Set radio aside.

STEP 2. Place the VSM G3 flush against the side and rear of the radio cavity bezel as shown in Photo #2. Use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. With a 5/64" bit and drill, drill out marked locations for the pilot holes. Do not drill more than 1/4" of an inch. Place the VSM G3 flush to the dash over the pilot holes and secure the mount to the dash with the three (3) provided #8 x 1/2" screws.

NOTE: You may choose a mounting location to either the right or left side of the radio.

STEP 3. Reconnect the wiring to the radio and carefully place the radio back in the radio cavity (until you hear it "click" back into place). You have successfully installed your VSM G3. **NOTE:** The radio should fit snugly back into place due to the screw heads securing the VSM G3 to the dash bezel.

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com