

Hyundai Sonata 2002-2005

PART NUMBER: MV-50-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.


When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).


TOOLS REQUIRED: #2 Phillips screwdriver, drill and 5/64" bit, Dash Trim Removal Tool (DTRT), marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of radio

STEP 1. Insert dash trim tool behind upper-left corner of the air vents and radio trim bezel. Photo #1. Using a gentle twisting motion, pry outward to release all the clips. Disconnect wiring harnesses and set bezel aside.





STEP 4. Assemble the dash in reverse order, securing all clips and wiring. This completes the installation of your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **VSM G3TM**. **Pro.Fit** International may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit** International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



View Instruction & Updates
Online at
www.pro-fit-intl.com