

Mazda5 2008-2010

GZ VSW

PART NUMBER: MV-50-03-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.


When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: 5/64" drill bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws, Phillips screwdriver

LOCATION: Right of Radio

STEP 1. Open glove box and place the VSM G3 flush to the glove box wall as pictured in Photo #2. Be sure to attempt to place the VSM G3 in the exact location as pictured, and that the VSM G3 ball provides plenty of clearance for the glove box to open.



STEP 3. Place the VSM G3 over the pilot holes and secure the mount to the dash molding using the two (2) provided #8 x 1/2" screws and secure, using a Phillips screwdriver. Once the VSM G3 has been secured and is in place, close the glove box. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3TM. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 314 West 86th Street Bloomington, MN 55420

Ph: 952.641-4700 or 800.388.0073 Fx: 952.641.4701