

## Honda CRV 2002-2006

PART NUMBER: MV-50-03-G3



## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: #2 Phillips screwdriver, drill and 5/64" bit, Dash Trim Removal Tool (DTRT), marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of radio

STEP 1. Remove two (2) #2 Phillips screws from the bottom of the air vent assembly. Pull vent out and let hang down. Next, remove the radio trim bezel. (Photo #1). Insert the DTRT behind the upper right corner of the bezel; using a gentle twisting motion, gently pry outward around the bezel until all clips are released. Set aside.

**STEP 2.** Hold the VSM G3 above the clip hole. Photo #2. Using the G3 as a guide, mark the location of two (2) screw holes. Set G3 aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the G3 over the pilot holes, insert two (2) #8 x 1/2" screws and tighten.

**STEP 3.** Assemble the dash in reverse order. This completes the installation of your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.







**Pro.Fit** International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **VSM G3<sup>TM</sup>**. **Pro.Fit** International may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit** International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

