



Jaguar X-Type (2002-2004)

PART NUMBER: MV-50-03-L



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.


TOOLS REQUIRED: #2 Phillips screwdriver, drill and 5/64" bit, Dash trim removal tool (DM-40-22), 10mm

PARTS INCLUDED: nut driver, marking pen


Pro.Fit Legend, instructions, two (2) # 8 x 1/2" screws.

LOCATION: Right of climate control

STEP 1. The instructions are the same for **automatic** and **manual** transmissions. Begin by removing the trim bezel from around the gear shifter. Set the parking brake and put the gear shift into neutral. Insert a hook tool behind the shift bezel and pull up gently to release a retainer clip. Work the trim tool around the bezel until all four (4) clips are loose. **(Photo 1)**. The four (4) clip holes are circled). Lift bezel off automatic shifter and set aside. On manual shifter, **(Photo 2)**, lift boot assembly enough to reveal two (2) Phillips screws. **(Photo 1)**.



STEP 2. Remove the two (2) Phillips screws in front of the shifter. Pull the ashtray assembly out, leaving the wiring harness connected, and set aside. There is a thin, black plastic strip at the top of the ashtray cavity that is held in place with two (2) clips. Take off this panel with a trim tool and remove the two (2) T-30 Torx screws from underneath it. Using a trim tool, remove the trim bezel from above the GPS monitor to reveal two (2) T-30 Torx screws. Remove these screws. Slide the radio / GPS module out of its cavity and let it hang down. **Do Not Disconnect any wiring to the radio / GPS module.**



STEP 3. Press the Legend against the dash, right of the climate control. **(Photo 3)**. Align the top Legend screw hole with the Torx screw and mark the location of the top and bottom holes. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the **LEGEND** over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.



STEP 4. Re-assemble the dash in reverse order, remembering to put the gear shift back into park and release the parking break. This completes the installation of your Legend.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

