

Ford Expedition 2007-2010

Legend

Part Number: MV-50-03-L

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Tools Needed: Dash Trim Removal Tool, 5/64" drill bit and drill Parts Included: VSM Legend, Instructions, Two (2) #8 1/2" Screws

Location: Right of Climate Control

Step One: Begin by inserting the dash trim removal tool into the dash bezel to the right of the radio. Release the first of six clips located in the top right hand corner of the dash bezel that surrounds the radio and climate control, and work the dash trim removal tool in a clockwise rotation around the bezel. After the dash bezel has been released, remove the wiring connected to the bezel and place the bezel aside.

Step Two: Place the VSM flush up against the side wall of the dash, as shown in picture #2. Once the VSM is in its correct location and flush up against the dash, use a marking pen to mark the location of the pilot holes, and then set the VSM aside. Using a 5/64" drill bit and drill, carefully drill out the pilot holes and place the VSM over the drilled out holes. Screw the VSM into the dash using the provided screws.

Step Three: Place the dash back together again in reverse order, making sure to carefully replace all of the wiring back in its original order. This completes the installation of your Pro.Fit Legend.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

